

Release Notes

CCURDPRC (WC-DPRC)



<i>Driver</i>	ccurdprc (WC-DPRC)	
<i>OS</i>	RedHawk (CentOS or Ubuntu based)	
<i>Vendor</i>	Concurrent Real-Time	
<i>Hardware</i>	Digital Programmable Resister Card (DPRC)	
<i>Author</i>	Darius Dubash	
<i>Date</i>	October 2 nd , 2020	<u>Rel 2020.2</u>



This page intentionally left blank

Table of Contents

- 1. INTRODUCTION 1
- 2. REQUIREMENTS 1
- 3. DOCUMENTATION 1
- 4. INSTALLATION AND REMOVAL 1
 - 4.1. Hardware Installation 1
 - 4.2. Software Installation 2
 - 4.3. Software Removal 4
- 5. AUTO-LOADING THE DRIVER 4
- 6. TESTING AND USAGE 5
- 7. RE-BUILDING THE DRIVER, LIBRARY AND TESTS..... 5
- 8. SOFTWARE SUPPORT..... 6
 - 8.1. Device Configuration 6
 - 8.2. Library Interface..... 6
 - 8.3. Debugging 6
- 9. NOTES AND ERRATA 9
- APPENDIX A: EXTERNAL CONNECTIONS AND PIN-OUTS 10
- APPENDIX B: EXTERNAL CONNECTIONS AND PIN-OUTS 11
- APPENDIX C: THE DIGITAL PROGRAMMABLE RESISTANCE CARD 12

This page intentionally left blank

1. Introduction

This document assists the user in installing the CCUR-PCIe-DPRC Linux **ccurdprc** driver and related software on the RedHawk OS for use with the CCUR-PCIe Digital Programmable Resister Card (**DPRC**). The directions in this document supersede all others – they are specific to installing the software on Concurrent Real-Time's RedHawk systems. Other information provided as part of this release, when it may contradict these directions, should be ignored and these directions should prevail.

For additional information on this driver and usage refer to the **ccurdprc** man page.

Features and Characteristics of the DPRC are:

- 16-channel Digital Programmable Resistance
- 45 to 1M Ohm Range (In 5 Ohm Steps)
- 10 Ohm Low Scale Selection
- +/-14V @ 10 Milliamp
- Open, Ground and V+ Fault Insertion
- Galvanic Isolation
- Overvoltage Protection
- Overcurrent Protection
- Analog Devices AD5293 Digital Potentiometers
- Industry Standard SCSI 68-pin Connector for I/O
- PCI Express x1 Revision 1.0a
- NIST Traceable Calibration Standard (Optional)

2. Requirements

- CCUR-DPRC PCIe board physically installed in the system.
- Selected versions of RedHawk Revision 5.4, 6.0, 6.3, 6.5, 7.0, 7.2 and 7.3. Actual supported versions depend on the driver being installed.

3. Documentation

- PCIe Digital Programmable Resister Card (DPRC) Software Interface by Concurrent Real-Time.
- PCIe Digital Programmable Resister Card (DPRC) Design Specification by Concurrent Real-Time.

4. Installation and Removal

4.1. Hardware Installation

The CCUR-DPRC card is a Gen 1 PCI Express product and is compatible with any PCI Express slot. The board must be installed in the system before attempting to use the driver.

The **ccurdprc** driver is designed to support IRQ sharing. If this device's IRQ is being shared by another device then this driver's performance could be compromised. Hence, as far as possible, move this board into a PCI slot who's IRQ is not being shared with other devices. The default driver configuration uses MSI interrupts. If the kernel supports MSI interrupts, then sharing of interrupts will not occur, in which case the board placement will not be an issue.



Caution: when installing the card insure the computer is powered off and the machine's power cord is disconnected. Please observe electrostatic discharge precautions such as the use of a grounding strap.

An `'lspci -v'` or the `'lsirq'` command can be used to determine the IRQs of various devices in the system.

```
# lspci -vv -d1542:9310
```

08:04.0 System peripheral: Concurrent Computer Corporation Device 9310 (rev 01)

Subsystem: PLX Technology, Inc. Device 9056

Control: I/O+ Mem+ BusMaster+ SpecCycle- MemWINV+ VGASnoop- ParErr- Stepping- SERR- FastB2B- DisINTx-

Status: Cap+ 66MHz+ UDF- FastB2B+ ParErr- DEVSEL=medium >TAbort- <TAbort- <MAbort- >SERR- <PERR- INTx-

Latency: 96, Cache Line Size: 32 bytes

Interrupt: pin A routed to IRQ 55

Region 0: Memory at c4c01000 (32-bit, non-prefetchable) [size=512]

Region 2: Memory at c4c00000 (32-bit, non-prefetchable) [size=2K]

Capabilities: <access denied>

```
# lsirq
```

55 08:04.0 Concurrent Computer Corporation Unknown device (rev 01)

After installing the card, reboot the system and verify the hardware has been recognized by the operating system by executing the following command:

```
# lspci -d 1542:9310
```

For each CCUR-DPRC PCIe board installed, a line similar to one of the following will be printed, depending on the revision of the system's `/usr/share/hwdata/pci.ids` file:

08:04.0 System peripheral: Concurrent Computer Corporation Device 9310 (rev 01)

If a line like the above is not displayed by the `lspci` command, the board has not been properly installed in the system. Make sure that the device has been correctly installed prior to attempting to use the software. One similar line should be found for each installed card.

4.2. Software Installation

Concurrent Real-Time™ port of the `ccurdprc` software is distributed in RPM format for CentOS and DEB format for Ubuntu OS on a CD-ROM. Source for the API library and kernel loadable driver are not included, however, source for example test programs as well as documentation is provided in PDF format.

The software is installed in the `/usr/local/CCRT/drivers/ccurdprc` directory. This directory will be referred to as the “top-level” directory by this document.



Warning: Before installing the software, the kernel build environment **must** be set up and match the current OS kernel you are using. If you are running one of the preconfigured kernels supplied by Concurrent Real-Time and have not previously done so, run the following commands while logged in as the `root` user before installing the driver software:

```
# cd /lib/modules/`uname -r`/build
# ./ccur-config -c -n
```

If you have built and are running a customized kernel configuration the kernel build environment should already have been set up when that custom kernel was built.

To install the **ccurdprc** package, load the CD-ROM installation media and issue the following commands as the **root** user. The system should auto-mount the CD-ROM to a mount point in the **/media** or **/run/media** directory based on the CD-ROM's volume label – in this case **ccurdprc_driver**. The example's **[user_name]** may be **root**, or the logged-in user. Then enter the following commands from a shell window:

```
== as root ==
    --- on RedHawk 6.5 and below ---
# cd /media/ccurdprc_driver
    --- or on RedHawk 7.0 and above ---
# cd /run/media/[user_name]/ccurdprc_driver

# rpm -ivh ccurdprc_RedHawk_driver*.rpm (on a CentOS based system)
    --or--
# dpkg -i ccurdprc_RedHawk_driver*.deb (on an Ubuntu based system)

# cd /
# eject
```

On successful installation, the source tree for the **ccurdprc** package, including the loadable kernel module, API libraries, and test programs is extracted into the **/usr/local/CCRT/drivers/ccurdprc** directory by the rpm installation process, which will then compile and install the various software components.

The loadable kernel module is installed in the **/lib/modules/`uname -r`/misc** directory.

Once the package is installed, the driver needs to be loaded with one of the following commands:

```
== as root ==
# cd /usr/local/CCRT/drivers/ccurdprc
# make load
    --- or on RedHawk 6.5 and below ---
# /sbin/service ccurdprc start
    --- or on RedHawk 7.0 and above ---
# /usr/bin/systemctl start ccurdprc
```

Issue the command below to view the boards found by the driver:

```
# cat /proc/ccurdprc

Version          : 23.1.1
Built           : Tue Apr 14 12:33:40 EST 2020
Boards          : 1
    card=0: [08:04.0] bus=8, slot=4, func=0, irq=55, msi=1, ID=680593,
BoardInfo=0x93100102
```

Note: With RedHawk 7.5 you may see a cautionary message similar to the following when the **ccurdprc** driver is loaded on the system console or via **dmesg** command:

```
CHRDEV "ccurdprc" major number 233 goes below the dynamic allocation range
```

As documented in the kernel driver **Documentation/devices.txt** file a range of character device numbers from 234 to 254 are officially available for dynamic assignment. Dynamic assignments start at 254 and grow downward. This range is sometimes exceeded as additional kernel drivers are loaded. Note that this was also the case with earlier kernels – the newer 7.5 kernel has added a runtime check to produce this warning message that the lower bound has been exceeded, not reduced the range of numbers officially available for dynamic assignment. If you see this message please verify the assigned number(s) isn't being used by a device installed on your system.

4.3. Software Removal

The **ccurdprc** driver is a dynamically loadable driver that can be unloaded, uninstalled and removed. Once removed, the only way to recover the driver is to re-install the **rpm** or **deb** from the installation CDROM:



If any changes have been made to the driver package installed in **/usr/local/CCRT/drivers/ccurdprc** directory, they need to be backed up prior to invoking the removal; otherwise, all changes will be lost.

```
== as root ==
# rpm -e ccurdprc      (driver unloaded, uninstalled, and deleted – on an RPM based system)
  --or--
# dpkg -P ccurdprc    (driver unloaded, uninstalled, and deleted – on an Debian based
                      system)
```

If, for any reason, the user wishes to un-load and uninstall the driver and not remove it, they can perform the following:

```
== as root ==
# cd /usr/local/CCRT/drivers/ccurdprc
# make unload          (unload the driver from the kernel)
  --- or on RedHawk 6.5 and below ---
# /sbin/service ccurdprc stop
  --- or on RedHawk 7.0 and above ---
# /usr/bin/systemctl stop ccurdprc
```

To uninstall the **ccurdprc** driver, do the following after it has been unloaded:

```
=== as root ===
# cd /usr/local/CCRT/drivers/ccurdprc
# make uninstall      (uninstall the driver and library)
```

In this way, the user can simply issue the **'make install'** and **'make load'** in the **/usr/local/CCRT/drivers/ccurdprc** directory later to re-install and re-load the driver.

5. Auto-loading the Driver

The **ccurdprc** driver is a dynamically loadable driver. Once you install the package or perform the **'make install'**, appropriate installation files are placed in the **/etc/rc.d/rc*.d** or **/usr/lib/systemd/systemd** directories so that the driver is automatically loaded and unloaded when Linux is booted and shutdown. If, for any reason, you do not wish to automatically load and unload the driver when Linux is booted or shutdown, you will need to manually issue the following command to enable/disable the automatic loading of the driver:

```
=== as root ===
  --- on RedHawk 6.5 and below ---
# /sbin/chkconfig --add ccurdprc      (enable auto-loading of the driver)
# /sbin/chkconfig --del ccurdprc     (disable auto-loading of the driver)

  --- or on RedHawk 7.0 and above ---
# /usr/bin/systemctl enable ccurdprc  (enable auto-loading of the driver)
# /usr/bin/systemctl disable ccurdprc (disable auto-loading of the driver)
```


6. Testing and Usage

Build and run the driver test programs, if you have not already done so:

```
# cd /usr/local/CCRT/drivers/ccurdprc
# make test                               (build the test programs)
```

Several tests have been provided in the `/usr/local/CCRT/drivers/ccurdprc/test` directory and can be run to test the driver and board.

```
=== as root ===
# cd /usr/local/CCRT/drivers/ccurdprc
# make test                               (build the test programs)
# ./test/ccurdprc_dump                    (dump all board resisters)
# ./test/ccurdprc_rdreg                    (display board resisters)
# ./test/ccurdprc_reg                      (Display board resisters)
# ./test/ccurdprc_regedit                  (Interactive board register editor test)
# ./test/ccurdprc_tst                      (Interactive test to test driver and board)
# ./test/ccurdprc_wreg                      (edit board resisters)
# ./test/Eeprom/ccurdprc_eeprom            (Eeprom: Burn Eeprom)

# ./test/Flash/ccurdprc_flash              (Flash: Flash firmware)
# ./test/Flash/ccurdprc_fwreload           (Flash: Firmware reload)

# ./test/lib/ccurdprc_adc_calibrate         (library: display or calibrate)
# ./test/lib/ccurdprc_disp                  (library: display, program & test)
# ./test/lib/ccurdprc_fault_protection     (library: display fault protection information)
# ./test/lib/ccurdprc_fault_trip_test      (library: perform fault trip testing)
# ./test/lib/ccurdprc_identify              (library: identify cards in the system)
# ./test/lib/ccurdprc_info                  (library: provide information of all boards)
# ./test/lib/ccurdprc_tst_lib               (library: Interactive test for driver & board)
```

7. Re-building the Driver, Library and Tests

If for any reason the user needs to manually rebuild and load an *installed rpm* or *deb* package, they can go to the installed directory and perform the necessary build.



Warning: Before installing the software, the kernel build environment **must** be set up and match the current OS kernel you are using. If you are running one of the preconfigured kernels supplied by Concurrent Real-Time and have not previously done so, run the following commands while logged in as the root user before installing the driver software:

```
# cd /lib/modules/`uname -r`/build
# ./ccur-config -c -n
```

If you have built and are running a customized kernel configuration the kernel build environment should already have been set up when that custom kernel was built.

To build the driver and tests:

```
=== as root ===
# cd /usr/local/CCRT/drivers/ccurdprc
# make clobber    (perform cleanup)
# make            (make package and build the driver, library and tests)
```

(Note: if you only wish to build the driver, you can enter the **'make driver'** command instead)

After the driver is built, you will need to install the driver. This install process should only be necessary if the driver is re-built with changes.

```
=== as root ===
# cd /usr/local/CCRT/drivers/ccurdprc
# make install      (install the driver software, library and man page)
```

Once the driver and the board are installed, you will need to **load** the driver into the running kernel prior to any access to the CCUR DPRC board.

```
=== as root ===
# cd /usr/local/CCRT/drivers/ccurdprc
# make load        (load the driver)
```

8. Software Support

- This driver package includes extensive software support and test programs to assist the user in communicating with the board. Refer to the PCIe Digital Programmable Resister Card (DPRC) Design Specification by Concurrent Real-Time for more information on the product.

8.1. Device Configuration

After the driver is successfully loaded, the device to card association file **ccurdprc_devs** will be created in the **/usr/local/CCRT/drivers/ccurdprc/driver** directory, if it did not exist. Additionally, there is a symbolic link to this file in the **/usr/lib/config/ccurdprc** directory as well. If the user wishes to keep the default one-to-one device to card association, no further action is required. If the device to card association needs to be changed, this file can be edited by the user to associate a particular device number with a card number that was found by the driver. The commented portion on the top of the **ccurdprc_devs** file is automatically generated every time the user issues the **'make load'** or **'/sbin/service ccurdprc start'** (on RedHawk 6.5 and below) or **'/usr/bin/systemctl start ccurdprc'** (on RedHawk 7.0 and above) command with the current detected cards, information. Any device to card association edited and placed in this file by the user is retained and used during the next **'make load'** or **'/sbin/service ccurdprc load'** or **'/usr/bin/systemctl start ccurdprc'** process.

If the user deletes the **ccurdprc_devs** file and recreates it as an empty file and performs a **'make load'** or if the user does not associate any device number with card number, the driver will provide a one to one association of device number and card number. For more information on available commands, view the commented section of the **ccurdprc_devs** configuration file.



Warning: If you edit the **ccurdprc_devs** file to associate a device to a card, you will need to re-issue the **'make load'** or **'/sbin/service ccurdprc start'** or **'/usr/bin/systemctl start ccurdprc'** command to generate the necessary device to card association. This device to card association will be retained until the user changes or deletes the association. **If any invalid association is detected, the loading of the driver will fail.**

8.2. Library Interface

There is an extensive software library that is provided with this package. For more information on the library interface, please refer to the PCIe Digital Programmable Resister Card (DPRC) Software Interface by Concurrent Real-Time for more information.

8.3. Debugging

This driver has some debugging capability and should only be enabled while trying to trouble-shoot a problem. Once resolved, debugging should be disabled otherwise it could adversely affect the performance and behavior of the driver.

To enable debugging, the **Makefile** file in **/usr/local/CCRT/drivers/ccurdprc/driver** should be edited to un-comment the statement (remove the preceding '#'):

```
# BUILD_TYPE=debug
```

Next, use and install the debug driver

```
# cd /usr/local/CCRT/drivers/ccurdprc/driver
# make
# make install
```

Next, edit the **ccurdprc_config** file in **/usr/local/CCRT/drivers/ccurdprc/driver** to un-comment the statement (remove the preceding '#'):

```
# ccurdprc_debug_mask=0x00002040
```

Additionally, the value of the debug mask can be changed to suite the problem investigated. Once the file has been edited, the user can load the driver by issuing the following:

```
# cd /usr/local/CCRT/drivers/ccurdprc/driver
# make load
```

The user can also change the debug flags after the driver is loaded by passing the above debug statement directly to the driver as follows:

```
# echo "ccurdprc_debug_mask=0x00082047" > /proc/driver/ccurdprc
```

Following are the supported flags for the debug mask as shown in the **ccurdprc_config** file.

```
#####
#
#      D_ENTER      0x00000001 /* enter routine */      #
#      D_EXIT      0x00000002 /* exit routine */        #
#
#      D_L1        0x00000004 /* level 1 */                #
#      D_L2        0x00000008 /* level 2 */                #
#      D_L3        0x00000010 /* level 3 */                #
#      D_L4        0x00000020 /* level 4 */                #
#
#      D_ERR       0x00000040 /* level error */            #
#      D_WAIT      0x00000080 /* level wait */            #
#
#      D_INT0      0x00000100 /* interrupt level 0 */      #
#      D_INT1      0x00000200 /* interrupt level 1 */      #
#      D_INT2      0x00000400 /* interrupt level 2 */      #
#      D_INT3      0x00000800 /* interrupt level 3 */      #
#      D_INTW      0x00001000 /* interrupt wakeup level */ #
#      D_INTE      0x00002000 /* interrupt error */        #
#
#      D_RUNTIME   0x00010000 /* display read times */    #
#      D_WTIME     0x00020000 /* display write times */    #
#      D_REGS      0x00040000 /* dump registers */        #
#      D_IOCTL     0x00080000 /* ioctl call */            #
#
#      D_DATA      0x00100000 /* data level */            #
#      D_DMA       0x00200000 /* DMA level */              #
#      D_DBUFF     0x00800000 /* DMA buffer allocation */  #
#
#      D_NEVER     0x00000000 /* never print this debug message */ #
#      D_ALWAYS   0xffffffff /* always print this debug message */ #
#      D_TEMP     D_ALWAYS /* Only use for temporary debug code */ #
#####
```

Another variable *ccurdprc_debug_ctrl* is also supplied in the *ccurdprc_config* that the driver developer can use to control the behavior of the driver. The user can also change the debug flags after the driver is loaded by passing the above debug statement directly to the driver as follows:

```
# echo "ccurdprc_debug_ctrl=0x00001234" > /proc/driver/ccurdprc
```


In order to make use of this variable, the driver must be coded to interrogate the bits in the *ccurdprc_debug_ctrl* variable and alter its behavior accordingly.

9. Notes and Errata

- The board is designed to protect itself from excess voltage and current faults so as not to damage it. Programmable trip points are fine-tuned to perform this function. It is imperative that the user does not attempt to change these trip thresholds as that could damage the card.
- This card does not use interrupts or performs DMA.
- It is possible that *lspci* calls will still display the device with the old name of “**Concurrent Computer Corporation**” instead of “**Concurrent Real-Time**” if the OS has not been updated.
- The potentiometers must be enabled before the ADC’s are enabled. The ADC’s may generate an error if this sequence is not followed.
- The ADC’s should also be disabled if the potentiometers are disabled to follow the sequence for re-enabling.
- A potentiometer is considered “activated” after the first resistance value has been written to it.
- A potentiometer is considered “powered down” if the test register has selected power down and the potentiometer is then activated.
- Calibration voltages (+2.5V, +10V & -10V) can only be selected if none of the potentiometers have been activated or if they are all powered down.
- Calibration currents (+8ma, -8ma & +16ma) can only be selected if none of the potentiometers are powered down.
- External I/O (including fault insertion) for a channel can only be selected if the potentiometer is active and if no sections are powered down or all sections are powered down.
- External fault switch testing for a channel can only be selected if the potentiometer is not active.
- The potentiometers must be disabled to de-activate them. This is the only way to restore any potentiometer from a powered down state or a forced failed condition.
- An electronic fuse trip condition will suspend all operations to the affected channel until the condition is cleared. The affected channels potentiometer will have to be re-written to restore the desired value.

Appendix A: External Connections and Pin-outs

The input/output signals from the DPRC are connected via an industry standard 68-pin SCSI type connector with the following pin-out:




Appendix B: External Connections and Pin-outs

The DPRC has a single multicolor LED indicator located at the top front edge of the board visible via a hole in the front panel. If the board is in a reset state the indicator will be solid Red. After reset is complete, the indicator will cycle through Red, Green and Blue for approximately 1 second each as a lamp test. If the indicator remains Red after reset is complete it would indicate a board malfunction. Other states of the board during operation are indicated as follows:

Color	Description	Input/Outputs
Red	Board in Reset	Not Active
Green	Board Operational	Not Active
Blue	Board Operational	Active

- 1) The Green or Blue indicators will *flash* once per second if the Identify Board bit is set.
- 2) The Blue indicator will *blink* twice per second if any channel has been tripped offline with an electronic fuse condition.

Appendix C: The Digital Programmable Resistance Card



This page intentionally left blank